

Personal Assistance, Product Specs, & "How-to" Questions:


Asistencia personal, especificaciones del producto y preguntas sobre "cómo hacerlo":

Aide personnelle, spécifications du produit et questions "pratico-pratiques":

1-800-732-8238

pfisterfaucets.com

HHL-VRVL/940-694




Note: R89-VRV* Thermostatic Trim only uses one lever. Please store second lever.


Nota: El trim termostático R89-VRV* solo usa una palanca. Guarde la segunda palanca.

Remarque : La garniture thermostatique R89-VRV* n'utilise qu'un seul levier. Veuillez ranger le deuxième levier.

Align to hub
Alinear con el cubo
Aligner sur le moyeu




HHL-VRVT/940-695



Align to hub
Alinear con el cubo
Aligner sur le moyeu



HHL-VRVX/940-707



Align to hub
Alinear con el cubo
Aligner sur le moyeu

